


Water Flow Diagram

Please read this manual carefully before you use this equipment




Trouble Shooting

Please read this manual carefully before you use this equipment

Symptom	Probability	Solution
Power Failure	Is the power plug rightly inserted in electric outlet?	Please put the power plug in the right position
	Is the fuse disconnected?	Please replace or connect the fuse tightly
Cooling System Failure	Directly in the sunlight or any heat source?	Avoid the heat and direct ray of sunlight
	Insufficient distance from wall?	Maintain sufficient distance at least 10cm from the wall
	Huge amount of water consumption before cooling?	Wait until the unit completing the cooling process
Heating System Failure	Hot water switch turned off?	Turn on hot wate switch please
	Huge amount of water consumption before heating?	wait until the unit completing the heating process
Purifying System Failure	Tank is dried up?	Check service from tab water
	Filter get clogged up	Exchange the filter
Noise	Inadequate installation area?	Set the product on the solid level surface
Leakage	Disconnected tubes?	Confirm to connect tubes
	Problem occurs in the appliance?	Alter the power disconnected

Touch button and display



Hot Water Temperature Up – Hotter water button



Touch the hot temperature up button for 1 seconds to get hotter water. In this mode, touching the hot up button for a short time, after 2 minutes, hot up button turned off. During 2 minutes, hot temperature goes up. Touch the water discharging button to have Hotter water (85°C to 87°C).

Hot Water Locking/Unlocking



Touch this button for 5 seconds to lock hot water for Children Safety (Alarm sound ringing). To release hot water, touch this button for 5 seconds water (Alarm sound ringing).

Cold Water



Touch the cold water selection button to select cold water. Then touch the water discharging button to have cold water to be discharged.

Hot Water



Touch the hot water selection button to select hot water. Then touch the water discharging button to have hot water to be discharged.

Ambient (Pure) Water



Touch the Pure (warm) water selection button to select pure water. Then touch the water discharging button to have pure water to be discharged.

Water Discharging Button



(Hot, Cold, Pure) Water Come

Adjustable Water Amount



1. One cup : Touch the cold water selection button and then touch the water discharging button to get one cup (8 oz) of cold water.

2. Two cups : Touch two times the cold water selection button and then touch the water discharging button to get two cups (16oz) of cold water



3. Three cups : Touch three times the cold water selection button and then touch the water discharging button to get three cups of cold water

* Same way for pure water amount and hot water amount as cold water above.

ECO



There's no light at night, the purifier will not work. That means compressor and hot water tank will not work. Only light of the water discharging button will work. Compressor and hot water tank will automatically turn off at night (no light) and turn on when light. If you want to work all day long, turn off the eco switch in the PCB. Then, ECO function will not work.

(Warning when 1st installed purifier)

- Do not turn on the hot switch (red switch) until water comes from hot water.
- Water should be filled up hot water tank before turn on hot switch (If not, bi-metal will be popped up and then hot water tank will not work)
- To excel water come into hot water tank, touch hot water selection button and then press the water discharging button. There's air in the hot water tank when 1st installed. So, touch hot water selection button and press the water discharging button to get rid of the air and fill up water in the hot water tank